



Cuprinol All Purpose Wood Filler

About this product

Cuprinol All Purpose Wood Filler is a tough, durable wood filler for small repairs. Specifically formulated to flex with the natural movement of the wood. It can be sanded, painted, stained or varnished when dry. It is not suitable for gaps between floor boards. It is easier and more pleasant to use because of its solvent free and low odour non flammable formulation.

Key Benefits

- ✓ Formulated to flex with the natural movement of the wood
- ✓ Can be sanded when dry
- ✓ Can be painted, stained or varnished
- ✓ Non flammable
- ✓ Suitable for both interior and exterior use
- ✓ Solvent free, low odour

Special Features

- ✓ Can be sanded when dry
- ✓ Can be painted, stained or varnished
- ✓ Non flammable
- ✓ Formulated to flex with the natural movement of the wood
- ✓ Interior and Exterior
- ✓ Solvent free, low odour

Technical Information

Touch dry	Approximately 2 hours
Recoatable	Approximately 2 hours

Product Information

Typical Use

To get the best results make sure the surfaces to be painted are sound, clean and dry. (New surfaces particularly must be fully dry). Ensure surfaces are clean and dry. Knead tube to mix contents. Apply using a wet filling knife, or using the cartridge, apply along or in the repair area, smoothing with a wet knife where necessary, leaving the filler slightly proud for sanding. For deep holes build up in layers, allowing each layer to dry. Leave proud and when completely dry (normally 2 hours) sand down and dust off.

Composition

Key Benefits

Formulated to flex with the natural movement of the wood, Can be sanded when dry, Can be painted, stained or varnished, Non flammable, Suitable for both interior and exterior use, Solvent free, low odour

Pack size

250ML, 310ML, 500ML

Application Method

Ensure surfaces are clean and dry. Knead tube to mix contents. Apply using a wet filling knife, or using the cartridge, apply along or in the repair area, smoothing with a wet knife where necessary, leaving the filler slightly proud for sanding. For deep holes build up in layers, allowing each layer to dry. Leave proud and when completely dry (normally 2 hours) sand down and dust off. Tub: Stir well before use. Apply using a wet filling knife. For deep holes build in layers, allowing each layer to dry. Leave proud and when completely dry (normally 2 hours) sand down and dust off. Finish with stain, varnish or paint. When over painted, stained or varnished the filled area may differ in colour to the surrounding area; therefore we recommend filling and finishing a small test area first to ensure that the appearance is acceptable. Do not use with wood dye. Cartridge: Apply along or in the repair area, smoothing with a wet knife where necessary, leaving the filler slightly proud for sanding. For deep holes (greater than 5mm deep) build up in layers, allowing each layer to dry. Leave proud and when completely dry (normally 2 hours) sand down and dust off. Finish with stain, varnish or paint. When over painted, stained or varnished the filled area may differ in colour to the surrounding area; therefore we recommend filling and finishing a small test area first to ensure that the appearance is acceptable. Do not use with wood dye. For breaks in between filling release trigger on cartridge gun to avoid overspill. To get the best results with Cuprinol All Purpose Wood Filler, make sure surfaces to be filled are sound, clean and dry (new surfaces particularly must be

fully dry).